

Oloce PROFESSIONAL THUMB REST FOR

0 B 0 E

TON KOOMAN

Oboe

Important

To fully enjoy the MAESTRO Thumb Rest please read this manual carefully. It is as important to take ample time to get used to the new position of your thumb.

Oloce

Making music can be very relaxing – but it is also demanding, especially when performing at a high level. If you want to play comfortably and relaxed, and if you want to prevent long and short term physical problems, it is essential that you use an ergonomically adapted instrument. The OBOE Thumb Rest and other Kooiman products help you to easily realize this adaptation.


Using a traditional thumb rest, the instrument rests at the very end of the thumb. This places a heavy load on the thumb. The Kooiman OBOE Thumb Rest has the instrument resting between the two parts of the thumb. The illustrations alongside clearly show the difference. The OBOE strongly reduces the required muscle power. As the hand can be much more relaxed, the fingers gain additional freedom of movement.

Oloce

The third and fourth fingers can reach the lower part of the mechanism more easily. Compared to a traditional thumb rest, the OBOE Thumb Rest is located higher up the instrument. As a result, the thumb regains its natural position thumb rest rather than being pushed downward. The lightly curved thumb makes sure the instrument

Please note that the

thumb should always be thumb Rest







Kooiman OBOE

Oloce

in full contact with the thumb rest case.

Assembly To prevent damaging your instrument, it's best to have the Kooiman OBOE Thumb Rest assembled by your technician. Should you want to do it yourself, please carefully follow this manual:

- Remove the current thumb rest.
- Push the mounting plate (1) up to remove it from the case (2). Place the mounting plate against the body of the instrument across from the position of your first finger. The curved side of the plate should be against the body, its two holes (in horizontal position) facing up, and the plate itself parallel to the longitudinal axis of the instrument. The plate should be 17mm (0.945") below the top end of the bottom section of the oboe.

Oloce

- Use a 1.7 mm bit to drill a hole in the wall of the instrument, using one of the holes in the mounting plate as a guide. (Do not pierce the wall! Leave the drilling to your technician if you're not sure you can manage this without damaging the instrument.).
- Fasten the first screw. Repeat this for the other holes, one by one.
- Slide the case over the plate from the bottom up.

Adjustment

- Adjusting the OBOE Thumb Rest is easiest in cooperation with your technician.
- To properly adjust the thumb rest, you should be able to fully relax your right hand: It should not support the instrument. For that purpose you should sit relaxed on a straight-


Oloce

backed chair. Hold the horn in its playing position, the mouthpiece in your mouth, the bell resting on your knees. You can use your left hand to help balance the instrument.

- Check the height adjustment: Can you easily reach all keys? Adjust the height using Allenhead screws D and F. (Use the large
- screw D; the small one for

- Now place your right hand on the keys, your thumb in the hollow of the case. The screws (A1 and A2, B1 and B2, C) should be loosened just a bit; the padded thumb rest (3) moved
- base line Allen-head key for
- screw F.) The position of the

Oloce



 Place the padded thumb rest between the two thumb joints. The padded section should be parallel to the floor (see illustration). Lightly tighten screws A1 and A2, followed by C, and finally B1 and B2.

Oloce

Additional information

For additional information please visit our website at www.tonkooiman.com or send us an e-mail at info@tonkooiman.com.

Kooiman Thumb Rests

Other Ton Kooiman Thumb Rests are the



MAESTRO for clarinet, the ETUDE 2 for clarinet and oboe, the OEHLER for the German Oehlerclarinet with additional E/F key, the FORZA for saxophone, and the PRIMA for flute.

Oloce

Production and export

Ton Kooiman Thumb Rests are made and exported by Rokatec BV. Veldzigt 6. 3454 PW De Meern, The Netherlands, phone +31 30 6666 868, www.rokatec.com, info@rokatec.com.





